



# INSTALLING CARBON MONOXIDE DETECTORS

## INSTRUCTIONS - INSTALLING A WIRELESS CARBON MONOXIDE DETECTOR

- 1- Unpack the Honeywell wireless carbon monoxide detector and keep all instruction manuals for later use.
- 2- ALWAYS install all carbon monoxide detectors per local, national and fire codes. Fox Guard shall not be held liable for product installed incorrectly, or installations that do not meet current code requirements.
- 3- Place carbon monoxide in mechanical or unfinished areas. DO NOT install detectors near stoves or fireplaces. For maximum protection install heat detectors on each level and near gas sources such as HVAC, oil burners and other mechanical devices. See installation manual for detailed instructions.
- 4- Remove the RFID sticker from the included mounting base and place in the correct box and keep this sheet for programming later. DO NOT mix up these numbers.
- 5- Mark the mounting holes of the carbon detector base in the ceiling of the desired room to protect and be sure the detector is placed properly according to code and manufacturer guidelines. Pre drill the drywall anchors with a 7/32" drill bit only for the depth of the drywall. Insert the plastic drywall anchors fully and use #8 screws to secure the base. Remove the battery tab and attach the carbon detector to the base by aligning the tabs and rotating until it clicks in place.

Carbon Monoxide Detector 1 \_\_\_\_\_

Carbon Monoxide Detector 2 \_\_\_\_\_

Carbon Monoxide Detector 3 \_\_\_\_\_

Carbon Monoxide Detector 4 \_\_\_\_\_

*continued...*