



## INSTALLING RECESSED 3/8" CONTACTS

### INSTRUCTIONS - INSTALLING A HONEYWELL RECESSED 3/8" CONTACT

- 1- Carefully open the Honeywell contacts and save all manuals and parts for future use.
- 2- The 3/8" contact is designed to be mounted in a door jamb or window sill to protect each individual point of entry without being visible. New construction before drywall is by far the easiest way to install these type of contacts
- 3- In order to install the contact, you must drill a 3/8" diameter hole into the frame and door or window that is at least 1.5" in depth and match up to each other when the window or door is closed. The contact is then recessed into the door or window frame, and the matching magnet is recessed into the door or window itself, opposite the contact. The 944T should be installed in an area with a gap no wider than 3/4" to ensure that contact is made when the door or window is closed. The contact is also equipped with Honeywell's exclusive Staggered "T" terminals which make installation a breeze. The terminals eliminate splice and solder and are compatible with a standard sized screw driver. The 944T recessed contact is ideal for installations where you want no signs of security devices, as they require more work to install, but are invisible once properly set up.
- 4- Seal the contact and magnet upon insertion with silicone and wipe with a damp towel. Connect the contact wiring to your alarm wiring 22/2 using silicone filled crimps, and use a metal junction box and conduit where applicable.

Thank you for your purchase from Fox Guard Security. If you need further instruction for this specific product feel free to visit our support section of [Foxguardsecurity.com](http://Foxguardsecurity.com) or our video library on our growing You Tube channel.