



INSTALLING SURFACE MOUNT CONTACTS

INSTRUCTIONS - INSTALLING A HONEYWELL SURFACE MOUNT CONTACT

- 1- Carefully open the Honeywell contacts and save all manuals and parts for future use.
- 2- The surface mount contact is designed to be mounted on a door jamb or window sill to protect each individual point of entry. Existing and new construction before drywall is by far the easiest way to install these type of contacts
- 3- You will need to surface mount when installing your door contact or window contact. The contact should be installed on the door or window frame and the magnet should be installed on the door or window so that when the door or window is closed, the magnet and contact are flush and in close proximity. In fact, the contact has a magnet gap of 1" so the contact must not be further from the magnet than 1" when the door or window is closed. You can install the surface mount contact in almost any application as it has an operating temperature of -40° F to 94 ° F. The Honeywell window or door contact includes spacers, covers and mounting screws in addition to the contact and magnet. You can use the spacer to flush mount the contact to the magnet when your door or window frame is not flush with the door or window. The cover will conceal the wiring connections and the end of line resistor (EOLR) if you choose to install the resistor at the device instead of inside the alarm control panel.

Thank you for your purchase from Fox Guard Security. If you need further instruction for this specific product feel free to visit our support section of Foxguardsecurity.com or our video library on our growing You Tube channel.