



## INSTALLING A HONEYWELL TUXEDO TOUCH

### INSTRUCTIONS - INSTALLING A HONEYWELL TUXEDO TOUCH

- 1- Carefully open the Honeywell Tuxedo Touch package and save all manuals and parts for future use.
- 2- At least one 6160 Alpha keypad must be used to program the Vista 20P panel, the Tuxedo should be used as a secondary keypad. If desired you may keep one keypad close to the alarm system itself just for programming and testing purposes.
- 3- Mount the rear mounting plate to the desired location with the supplied drywall anchors and fasteners and connect a 4 conductor 22/4 quad wire to the terminals on the back of the Tuxedo keypad (Red, black, yellow, green) and document the MAC and CRC # located on the back of the keypad itself.
- 4- After initialization set the ECP and RIS address. If you are using one keypad leave the ECP address to 1, if you are using more than one power up the keypads one at a time and set each keypad to the appropriate ECP address. Vista 20P panels are able to use 1,2,5&6 as ECP
- 5- Configure the wireless or LAN connection.
- 6- Set the date and time. Setup > System > Time/date setup, enter an authorized code press apply and answer YES to the next prompt.
- 7- Setup the IP. Press Setup > IP Setup select type of connection. Select Wi-Fi ON if you will wirelessly connect to the local network or select LAN ON if you will hardwire an ethernet wire to the keypad
- 8- Refer to the the advanced setup owners and install guides for more features and troubleshooting sections.

Thank you for your purchase from Fox Guard Security. If you need further instruction for this specific product feel free to visit our support section of [Foxguardsecurity.com](http://Foxguardsecurity.com) or our video library on our growing You Tube channel.