



INSTALL WIRELESS MOTION DETECTORS

INSTRUCTIONS - INSTALLING A WIRELESS MOTION DETECTOR

- 1- Unpack the Honeywell wireless motion detector package and lay out all of the included parts. Locate the gray 3M mounting tape, if purchased. Remove the small 1/2" screw from rear plate.
- 2- Open the cover of the wireless motion by locating the small release tab on the bottom end and using a flathead screwdriver to gently pry open and release the cover lid.
- 3- Install the supplied lithium CR123 battery into the detector keeping the (+) oriented towards the correct direction.
- 4- Determine the best mounting location based on the following priority list:
 - Top priority - Main entry areas.
 - Second priority - Common areas with multiple entry doors.
 - Third priority - Basement area.
- 5- The ideal mounting height is 6.5' - 7.5' in a corner facing the desired area.
- 6- Use the supplied double sided tape (GOOD) or two #8 x 2 screws through the rear of the mounting plate into the corner itself (BEST).
- 7- Re-install the motion detector cover by aligning the top two mounting tabs and locking the motion down in place over the base.
- 8- Keep the RFID accessible for programming later.

Motion 1 _____

Motion 2 _____

Motion 3 _____