



INSTALL WIRELESS OUTDOOR CONTACTS

INSTRUCTIONS - INSTALLING A WIRELESS OUTDOOR CONTACT

1- Carefully open the Honeywell 5816OD wireless outdoor sensor packaging and save all parts and manuals for future reference.

2- The front of the sensor has one stainless steel screw to loosen and will simply lift off of the back plate. The inner plate will also pull away from the contact assembly revealing the battery location. Install 2 AA Lithium batteries (supplied) and place the RFID sticker in the supplied box for future programming purposes.

Outdoor 1



Outdoor 2



3- Secure the back plate of the contact with the supplied screws to the correct location of the desired door or window to protect. Common outdoor protection points are shed doors and exterior garage doors.

Shed doors - Mount the contact and magnet on the inside of the doors, within 1/2" of each other and the alignment markings properly aligned. Mount towards the top of the door to reduce the risk of damage.

Exterior Garage Doors - Mount the contact and magnet on the interior of the door, with the contact itself ideally on the door frame and magnet on the door at the top of the door, on the handle side. Properly align the markings on the contact and magnet.

4- Program the contact as loop 2, and determine whether you want a delay on the door (typical) or (perimeter) for a window. Test the contact operation by using the chime feature first, then after correct operation is ensured.