



INSTALLING A HONEYWELL VAM

INSTRUCTIONS - INSTALLING A HONEYWELL VISTA AUTOMATION MODULE

- 1- Carefully open the Honeywell VAM package and save all manuals and parts for future use.
- 2- Wiring connections - The VAM is a Z wave and automation controller that connects to the Vista 20P panel if there is no Tuxedo touch keypad selected. Keypad BUS (red,black,yellow & green)
- 3- Write down the network ID, WPA2 and default IP address from the back of the VAM and your router SSID and WPA2 password.
- 4- Refer to the VAM setup guide for in depth programming instructions and troubleshooting sections.

Thank you for your purchase from Fox Guard Security. If you need further instruction for this specific product feel free to visit our support section of Foxguardsecurity.com or our video library on our growing You Tube channel.