



INSTALLING A HONEYWELL SIREN

INSTRUCTIONS - INSTALLING A HONEYWELL INTERIOR SIREN

- 1- Carefully open the Honeywell siren and save all manuals and parts for future use.
- 2- The WAVE2 is also the perfect size to mount to a single gang electrical box. When wiring the WAVE2, connect to the siren or bell output from your alarm panel. The (-) from the bell output should wire to GND, and the (+) from the bell output should be wired to terminal #1 for a steady siren tone, and terminal #2 for a warble or varied siren tone.
- 3- The Honeywell siren has a unique hinged case that allows the siren to be installed and mounted without disassembly. You can mount the WAVE2 vertically or horizontally, flat on the wall, or in a corner all without any brackets or additional mounting equipment.
- 4- Ideal locations are near an interior doorbell location, or central spot close to the security panel.
- 5- Multiple sirens may be used as long as the proper power supply considerations are taken.

Thank you for your purchase from Fox Guard Security. If you need further instruction for this specific product feel free to visit our support section of Foxguardsecurity.com or our video library on our growing You Tube channel.